




BASIC OPERATING INSTRUCTIONS

ORYX200 REPEATER PANEL RANGE

PRODUCT CODE

ORYX202-R ORYX204-R
ORYX208-R





- **Level 1 Access:**
Allows SILENCE BUZZER operation only (CONTROLS ENABLED Yellow LED Off)
- **Level 2 Access:**
Allows full control (CONTROLS ENABLED Yellow LED On)



- **Level Access Control Switch:**
Turn clockwise ↻ to access Level 2



ORYX204-R 4 Zone Repeater Panel is shown



STEPS

NB: Controls must be enabled to perform SILENCE ALARM and RESET.

1. Press **SILENCE BUZZER:**
 - Internal buzzer will silence.
 - Fire LEDs will change from flashing to steady.
 The **SILENCE BUZZER** button's Yellow LED will switch on.
2. Press **SILENCE ALARM:**
 - Sounders will silence.
 The **SILENCE ALARM** button's Yellow LED will switch on.

VERIFY FOR FIRE OR A FALSE ALARM

IF FIRE CONDITION

1. Press **SOUND ALARM:**
 - Sounders will re-activate.
 The **SOUND ALARM** button's Yellow LED will switch on.
2. Contact Emergency Services.
3. Follow your standard Emergency Evacuation Procedure.

IF FALSE ALARM

Once false alarm has been confirmed:

- Press **RESET** and panel will return to Normal state.

NB: Reset can only be performed if controls are enabled.

STEPS

IF FAULT CONDITION

1. Press **SILENCE BUZZER**
 - Fault LEDs will change from flashing to steady.
2. Identify the Fault condition on the panel.
3. Contact your service provider.

- **EMERGENCY CONTACT DETAILS**
(place sticker here)

- **SERVICE PROVIDER CONTACT DETAILS**
(place sticker here)

• **DISCLAIMER:** Although the contents of our product literature have been prepared with the greatest care, Technoswitch can accept no liability whatsoever for any direct or indirect damages of any kind that may arise due to either errors or omissions in them, or amendments to products or other specifications following publication. © Technoswitch (Pty) Ltd



HEAD OFFICE — JOHANNESBURG
Cussonia Park, 3 Ridge Road, Laser Park, Johannesburg T +27 (0)11 794 9144 E info@technoswitch.co.za
CAPE TOWN T +27 (0)21 948 4575 ■ **DURBAN** T +27 (0)31 266 8843

www.technoswitch.co.za